

# **APPLICATION NOTE**

for

## **Init Setting Manual for USB Industrial**

22 October 2018

Prepared by:

**Jimmy Liang**

Decision-Computer RD department

USB Init Set USB\_Industrial\_initSet.exe is the tool software which can allow users to set init default value for output port in some USB Industrial products. You can follow the steps to set init value.

Step 1: Download USB\_Industrial\_initSet.zip and unzip.

Step 2 : Execute a "USB\_Industrial\_initSet.exe" and "Open Device"

Step 3 : Turn off the JP2 0~15 LED and JP3 0~15 you want.

Step 4 : Click the A button to set the initial value

Step 5 : If you want to set it, please "Close Device" and follow step 2.

